

Varemerke	Størrelse	Adapter	Flip Cover	Komplett sett	Adapter	Flip Cover	Komplett sett
<b>Apollo</b>							
Apollo X4i HD TB	3-12x56	TB ready	6821	6821	TB ready	6824	6824
Apollo X6i HD TB	1-6x24	TB ready	6821	6821	7904	6818	7921
Apollo X6i HD	2-12x50	7953	6992	6995	6886	6823	7933
Apollo X6i HD TB	2-12x50	TB ready	6821	6821	6886	6823	7933
Apollo X6i HD TB	3-18x56	TB ready	6821	6821	TB ready	6824	6824
Apollo X8i HD	1-8x24	TB ready	6821	6821	7904	6818	7921
<b>Kite</b>							
KITE B6	2-12x50	7947	6992	6998	6885	6822	7931
KITE B6	1-6x24	7947	6992	6998	7904	6818	7921
KITE K4	1-4x24	7952	6992	7944	7904	6818	7921
KITE K4	3-12x50	7952	6992	7944	8235	6822	7236
KITE KSP HD	2,5-10x50	8236	7912	7078	6886	6823	7933
KITE KSP HD	1-6x24	8236	7912	7078	7904	6818	7921
KITE KSP HD	1,6-10x42	8236	7912	7078	7907	7911	7237
KITE KSP HD	2-12x50	8236	7912	7078	8235	6822	7236
KITE KSP HD	2,5-15x56	8236	7912	7078	6862	6824	7238
KITE K6	1-6x24	7952	6992	7944	7904	6818	7921
KITE K6	1,6-10x42	7952	6992	7944	7907	7911	7237
KITE K6	2-12x50	7952	6992	7944	8235	6822	7236
KITE K6	2,5-15x56	7952	6992	7944	6862	6824	7238
<b>Leica</b>							
Leica Magnus	1-6,3x24	8371	6992	8350	7904	6818	7921
Leica Magnus	1,5-10x42	8371	6992	8350	6884	6822	7930
Leica Magnus	1,8-12x50	8371	6992	8350	6885	6822	7931
Leica Magnus	2,4-16x56	8371	6992	8350	6871	6824	7914
Leica ER	2.5-10x24				6884	6822	7930
Leica ER	3-12x50	7947	6992	6998	6885	6822	7931
Leica ER LRS	6,5-26x56	7947	6992	6998	6871	6824	7914
Leica PRS	5-30x56	7949	7912	7943	6862	6824	7238
Leica Amplus 6	1-6 x 24						
Leica Amplus 6	3-18 x 44						
Leica Amplus 6	2.5-15 x 50				8235	6822	7236
Leica Amplus 6	2.5-15 x 56				6862	6824	7238
Leica Fortis 6	1-6x24	8371	6992	8350	7904	6818	7921
Leica Fortis 6	1.8-12x42				6884	6822	7930
Leica Fortis 6	2-12x50	8371	6992	8350	6885	6822	7931
Leica Fortis 6	2,5-15x56	8371	6992	8350	6871	6824	7914
<b>Swarovski</b>							
Swarovski Z4	2,5-10x56	6840	6992	7940	6871	6824	7914
Swarovski Z4	3-12x50	6840	6992	7940	6886	6823	7933
Swarovski Z5 P	3.5-18x44	7948	7912	7937	6884	6822	7930
Swarovski Z5 P	5-25x52	7948	7912	7937	6874	6823	7919
Swarovski X5i	3.5-18x50				6885	6822	7931
Swarovski X5i	5-25x56				6871	6824	7914
Swarovski Z6/Z6i	1-6x24	7947	6992	6998	6851	6818	7917
Swarovski Z6/Z6i	1-6x24 EE	7947	6992	6998	6851	6818	7917
Swarovski Z6/Z6i	1,7-10x42	7947	6992	6998	6869	6992	7916
Swarovski Z6/Z6i	2-12x50	7947	6992	6998	6885	6822	7931
Swarovski Z6/Z6i	2,5-15x44	7947	6992	6998	6884	6822	7930
Swarovski Z6/Z6i	2,5x15x56	7947	6992	6998	6871	6824	7914
Swarovski Z6/Z6i	3-18x50	7947	6992	6998	6885	6822	7931
Swarovski Z6/Z6i	5-30x50	7947	6992	6998	6885	6822	7931
Swarovski DS	5-25x52P	7947	6992	6998			
Swarovski Z8i+	0.75-6x20	7947	6992	6998	7904	6818	7921
Swarovski Z8i+	1-8x24	7947	6992	6998	7904	6818	7921
Swarovski Z8/Z8i	0.75-6x20	7947	6992	6998	6851	6818	7917
Swarovski Z8/Z8i	1-8x24	7947	6992	6998	6851	6818	7917
Swarovski Z8/Z8i	1,7-13,3x42	7947	6992	6998	6869	6992	7916
Swarovski Z8/Z8i	2-16x50	7947	6992	6998	6885	6822	7931

Swarovski Z8/Z8i	3.5-28x50	7947	6992	6998	6885	6822	7931
Swarovski Z8/Z8i	2,3-18x56	7947	6992	6998	6871	6824	7914
Swarovski PV-line	1,5-6x42	6840	6992	7940	6869	6992	7916
Swarovski PV-line	2,5-10x42	6840	6992	7940	6869	6992	7916
Swarovski PV-line	3-12x50	6840	6992	7940	6885	6822	7931
<b>Zeiss</b>							
Zeiss Conquest	2-10x42	7948	7912	7937			
Zeiss Conquest	5-25x50	7948	7912	7937			
Zeiss Conquest	3.5-10x50	7949	7912	7943			
Zeiss Conquest	3-9x50	7949	7912	7943			
Zeiss Conquest	4.5-14x50	7949	7912	7943			
Zeiss Conquest DL	1.2-5x36	7949	7912	7943			
Zeiss Conquest HD5	2-10x42	7949	7912	7943			
Zeiss Conquest HD5	3-15x50	7949	7912	7943			
Zeiss Conquest V4	1-4x24	7949	7912	7943	7904	6818	7921
Zeiss Conquest V4	3-12x56	7949	7912	7943	6994	6824	7920
Zeiss Conquest V4	4-16X44	7949	7912	7943	6884	6822	7930
Zeiss Conquest V4	4-16x50	7949	7912	7943	6874	6823	7919
Zeiss Conquest V4	6-24x50	7949	7912	7943	6874	6823	7919
Zeiss Conquest V6	2.5-15X56	7947	6992	6998	6994	6824	7920
Zeiss Conquest V6	2-12X50	7947	6992	6998	6874	6823	7919
Zeiss Conquest V6	3-18X50	7947	6992	6998	6874	6823	7919
Zeiss Conquest V6	5-30X50	7947	6992	6998	6874	6823	7919
Zeiss Victory HT (Ikke diavari)	2.5-10x50	7908	7912	7934	6874	6823	7919
Zeiss Victory HT (Ikke diavari)	3-12x56	7908	7912	7934	6994	6824	7920
Zeiss Victory Diavari	6-24x56	7950	7912	6996			
Zeiss Victory Diavari	6-24x72	7950	7912	6996			
Zeiss Victory V8	1.1-8x30	8367	6992	8352	8370	6819	8351
Zeiss Victory V8	1.8-14x50	7956	6992	7945	6874	6823	7919
Zeiss Victory V8	2.8-20x56	7956	6992	7945	6994	6824	7920
Zeiss Victory V8	4,8-35x60	8367	6992	8352	6881	6824	8652

**Mål-basert - Når du ikke finner kikkertsiktet ovenfor.**

Det er ingen forskjell på om adapter eller deksel skal brukes foran(obj.) eller bak(okular) på kikkertsiktet. Adapterne nedenfor er av splittet type som lukkes/ strammes vha. skrue. Denne skruen må kun strammes forsiktig til, nok til at adapteret låses fast til kikkerten. Strammes skruen for mye kan adapteret skades.

Diameter Ø29,8 mm - Ø30,8 mm		7904	6818	7921	
Diameter Ø35,7 mm - Ø36,2 mm		8370	6819	8351	
Diameter Ø39,6 mm - Ø40,2 mm		7951	7912	7938	
Diameter Ø40,5 mm - Ø41,0 mm		7950	7912	6996	
Diameter Ø41,2 mm - Ø41,7 mm		7955	7912	7946	
Diameter Ø42,0 mm - Ø42,5 mm		7908	7912	7934	
Diameter Ø42,6 mm - Ø43,1 mm		7948	7912	7937	
Diameter Ø43,0 mm - Ø43,5 mm		7949	7912	7943	
Diameter Ø43,5 mm - Ø44,1 mm		7952	6992	7944	
Diameter Ø44,2 mm - Ø44,7 mm		8365	6992		
Diameter Ø44,7 mm - Ø45,2 mm		7954	6992	7939	
Diameter Ø45,2 mm - Ø45,7 mm		7953	6992	6995	
Diameter Ø45,5 mm - Ø46,0 mm		7947	6992	6998	
Diameter Ø46,0 mm - Ø46,5 mm		8366	6992		
Diameter Ø46,5 mm - Ø47,0 mm		8367	6992	8352	
Diameter Ø47,0 mm - Ø47,5 mm		7956	6992	7945	
Diameter Ø47,5 mm - Ø48,0 mm		8369	6992		

**PRISER**

	Adapter	Deksel	Komplett sett
Adapter type 1 (grønn fargekode)	kr 333	kr 333	kr 666
Adapter type 2 (blå fargekode)	kr 666	kr 333	kr 999

